

Cap spoiler Installation Manual





1. Check fitting:

Measure distance on both sides of the spoiler and align it centrally.

Mark end points on the car spoiler



2. Prepare spolier surface:

Use degreasing cloth to clean surface of spoiler that adjoins Maxton Design Cap Spoiler



Line up Maxton's Cap Spoiler with previously marked points, tear off red protecting tape and put Cap spoiler on the car.



Press strongly whole adjoining surface to make whole 3M tape stick to car.



4.



Support: www.maxtondesign.com/manuals

